


ASSEMBLY INSTRUCTIONS

TWIN HOUSE LOFT BED WITH SLIDE



WF313050/WF313051

ASSEMBLY INSTRUCTIONS



SAFETY WARNINGS



1. This bed is designed for use only mattress (es) meeting the following specifications on the upper bunk:
Upper bunk (bunk bed and tribed included)

Bed Type	Length	Width	Thickness
Twin Standard	74" - 75"	37 $\frac{1}{2}$ " - 38 $\frac{1}{2}$ "	6" max
2. Replacement parts, including additional guardrails, maybe obtained from any of our (GIGACLOUD TECHNOLOGY (USA) INC. 18961 ARENTH AVENUE CITY OF INDUSTRY, CA, 91748) dealers
3. Follow the information on the warnings appearing on the upper bunk bed end structure and on the carton. Do not remove warning label from bed.
4. Always use the recommended size mattresses or mattress supports, or both, to help prevent the likelihood of entrapment or falls.
5. Surface of mattress must be at least 5" (127mm) below the upper edge of guardrails.
6. Do not allow children under 6 years of age to use the upper bunk.
7. Periodically check and ensure that the guardrail, ladder, and other components are in their proper position, free from damage, and that all connectors are tight.
8. Do not allow horseplay on or under the bed and prohibit jumping on the bed.
9. Always use the ladder for entering and leaving the upper bunk.
10. Do not use substitute part. Contact the manufacture or dealer for replacement part.
11. Use of a night light may provide added safety precaution for a child using the upper bunk.
12. Always use guardrails on both long sides of the upper bunk. If the bunk bed will be placed next to the wall, the guardrail that runs the full length of the bed should be placed against the wall to prevent entrapment between the bed and wall.
13. The use of water or sleep flotation mattresses is prohibited.
14. **STRANGULATION HAZARD** - Never attach or hang items to any part of the bunk bed that are not designed for use with the bed; for example, but not limited to, hook, belts and jump ropes.
15. Keep these instruction for future reference.
16. Prohibit more than one person on upper bunk
17. We recommend assembling your bunk bed on the shipping carton to protect your floor or carpet.
18. Be certain all staples are out of the box before beginning assembly on the shipping carton.

ASSEMBLY INSTRUCTIONS

1. At the beginning :

Tighten all hardware.

Check metal parts for rust. If found, sand and repaint using a non-lead-based paint meeting the requirements of 16 CFR 1303.

Check all wood members for deterioration and splinters. Sand down splinters and replace deteriorating wood members.

Rake and check depth of loose fill protective surfacing materials to prevent compaction and to maintain appropriate depth. Replace as necessary.

2. Twice a month

Tighten all hardware.

Rake and check depth of loose fill protective surfacing materials to prevent compaction and to maintain appropriate depth. Replace as necessary.

3. Owners shall be responsible for maintaining the legibility of the warning labels.

4. Disposal Instructions-

There shall be instructions advising the owner to disassemble and dispose of the playground equipment in such a way that no unreasonable hazards will exist at the time the playground equipment is discarded.

5. The instructions shall also include the information found in Section 4 of the United States Consumer Product Safety Commission's (USCPSC) Outdoor Home Playground Safety Handbook or specific surfacing guidelines for the product consistent with the USCPSC Handbook. A copy of this section may be found in Appendix X2.

6. Observing the following statements and warnings reduces the likelihood of serious or fatal injury.

7. Specifying the number and weight of occupants that may safely use the equipment singly or simultaneously,

8. Recommending on-site adult supervision for children of all ages,

9. Warning the owner to instruct children not to use the equipment in a manner other than intended,

10. Warning the owner to instruct children not to get off equipment while it is in motion,

11. Warning the owner not to allow children to wear inappropriate items, such as but not limited to, loose fitting clothing, hood and neck drawstrings, scarves, cord-connected items, capes and ponchos. These items can cause death by strangulation.

12. Warning the owner to instruct children not to climb when the equipment is wet.

13. Warning the owner to instruct children not to attach items to the playground equipment that are not specifically designed for use with the equipment, such as, but not limited to, jump ropes, clothesline, pet leashes, cables and chain as they may cause a strangulation hazard

14. Warning the owner to instruct children to remove their bike or other sports helmet before playing on the playground equipment.


15. Warning the owner to dress children with well-fitting and full foot enclosing footwear. Examples of inappropriate footwear are clogs, flip flops, and sandals.

16. Place the equipment on level ground, not less than 6 ft (1.8 m) from any structure or obstruction such as a fence, garage, house, overhanging branches, laundry lines, or electrical wires

17. Do not install home playground equipment over concrete, asphalt, packed earth, grass, carpet, or any other hard surface. A fall onto a hard surface can result in serious injury or death to the equipment user

18. To prevent serious injury, cautionary statements shall be included which warn that children must not use the equipment until properly installed.
















ASSEMBLY INSTRUCTIONS



ASSEMBLY INSTRUCTIONS

PARTS LIST


























WF313050

11	Slats 	14pcs	28	Storage ladder bottom panel 	1pc
21	Storage ladder side panel 	1pc	29	Storage ladder bottom panel 	1pc
22	Storage ladder side panel 	1pc	30	Storage ladder between panel 	1pc
23	Storage ladder side panel 	1pc	31	Storage ladder door panel 	3pcs
24	Storage ladder side panel 	1pc	32	Storage ladder support 	6pcs
25	Storage ladder side panel 	1pc	33	Storage ladder back panel 	1pc
26	Storage ladder side panel 	1pc	34	Storage ladder back panel 	1pc
27	Storage ladder bottom panel 	1pc			

ASSEMBLY INSTRUCTIONS




























PARTS LIST

WF313051 Hardware in this SKU

1	Leg 	1pc	15	Roof top 	3pcs
2	Leg 	1pc	16	Front guard rails support 	1pc
3	Leg 	1pc	17	Back storage ladder support 	1pc
4	Leg 	1pc	18	Front storage ladder support 	2pcs
5	Side rails 	1pc	19	Storage ladder support 	2pcs
6	Side rails 	1pc	20	Storage ladder support 	2pcs
7	Guard rails 	3pcs	35	Slide panel 	1pc
8	Guard rails 	1pc	36	Slide support 	4pcs
9	Guard rails 	2pcs	37	Slide bottom panel 	1pc
10	Roof top support 	1pc	38	Slide left leg 	1pc
12	Headboard panels 	2pcs	39	Slide right leg 	1pc
13	Headboard panels 	6pcs	40	Back guard rails support 	1pc
14	Roof top 	1pc			


ASSEMBLY INSTRUCTIONS




HARDWARE LIST (WF313051)

A	Ø4x30		31PCS	K	1/4x25	 	5PCS
B	Ø4x20		6PCS	L	4x58		1PC
C	Ø3x15		18PCS	M	Ø10x40		62PCS
D	6.5x50		12PCS	N	Ø8x30		30PCS
E	1/4x110	 	16PCS	O	Ø 6.5x35		24PCS
F	1/4x90	 	10PCS	P	Ø15x12		24PCS
G	1/4x75	 	20PCS	Q	44x17x14		3PCS
H	1/4x65	 	12PCS	R	1/4x12		12PCS
I	1/4x35	 	6PCS	S	1/4x19		12PCS
J	1/4x30	 	5PCS	Phillip head screw Not include 			

ASSEMBLY INSTRUCTIONS


Step 1



M	Ø10x40		28PCS
E	1/4x110		16PCS
L	4x58		1PC

ASSEMBLY INSTRUCTIONS

Step 2



L

4x58



1PC

K


1/4x25









4PCS

ASSEMBLY INSTRUCTIONS


Step 3






F	1/4x90  	2PCS	M	Ø10x40 	14PCS
G	1/4x75  	18PCS	L	4x58 	1PC

ASSEMBLY INSTRUCTIONS

Step 4




				L	4x58		1PC
J	1/4x30		3PCS	K	1/4x25		1PC

ASSEMBLY INSTRUCTIONS

Step 5

First attach 2pcs part 11 to the front and end of the frame, between side rails. Then attach the remaining part 11 equidistantly between side rails.



A


Ø4x30






31PCS

ASSEMBLY INSTRUCTIONS


Step 6







O	Ø 6.5x35		16PCS
C	Ø3x15		6PCS
Q	44x17x14		3PCS


ASSEMBLY INSTRUCTIONS



Step 7



P	Ø15x12		4PCS	L	4x58		1PC
N	Ø8x30		4PCS	D	6.5x50		4PCS


Step 8






N	Ø8x30		6PCS	C	Ø3x15		4PCS
----------	-------	---	------	----------	-------	---	------


ASSEMBLY INSTRUCTIONS



Step 9



O	Ø 6.5x35		4PCS			
N	Ø8x30		6PCS	P	Ø15x12	 4PCS


Step 10



D	6.5x50		4PCS	L	4x58	 1PC
----------	--------	---	------	----------	------	---

ASSEMBLY INSTRUCTIONS

Step 11




P

Ø15x12



4PCS

Step 12



N

Ø8x30



6PCS

C


Ø3x15






4PCS


ASSEMBLY INSTRUCTIONS



Step 13



O	Ø 6.5x35		4PCS			
N	Ø8x30		4PCS	P	Ø15x12	 4PCS


Step 14



D	6.5x50		4PCS	L	4x58	 1PC
----------	--------	---	------	----------	------	---

ASSEMBLY INSTRUCTIONS

Step 15




P

Ø15x12



4PCS

Step 16



N

Ø8x30



4PCS

C


Ø3x15



4PCS

ASSEMBLY INSTRUCTIONS

Step 17




P

Ø15x12



4PCS

Step 18



M

Ø10x40



6PCS

F

1/4x90



6PCS

L


4x58





1PC

ASSEMBLY INSTRUCTIONS


Step 19





M	Ø10x40		2PCS
L	4x58		1PC


ASSEMBLY INSTRUCTIONS



Step 20



L	4x58		1PC
I	1/4x35		6PCS


Step 21



J	1/4x30		2PCS	L	4x58		1PC
----------	--------	---	------	----------	------	---	-----

ASSEMBLY INSTRUCTIONS

Step 22



B

Ø4x20



6PCS

Step 23


R

1/4x12



12PCS

S

1/4x19



12PCS

M


Ø10x40



10PCS

L

4x58



1PC

H



1/4x65






12PCS

ASSEMBLY INSTRUCTIONS

Step 24



M	Ø10x40		2PCS
L	4x58		1PC

F	1/4x90	 	2PCS
----------	--------	---	------